

Caster Replacement

1. Lay the chair on back



2. Remove all the casters by grabbing and pulling out.



3. Transfer casters by pressing in with thumb in shown position.

